



AquaSense®

Z6920/22 Gooseneck Sensor Faucets

Installation, Operation, Maintenance, and Parts-Manual



Z6920-XL



Z6922-XL

- ⚠ **CALIFORNIA WARNING:** Risk of cancer and reproductive harm from exposure to nickel (metallic and soluble compounds). See www.P65Warnings.ca.gov.
- ⚠ **AVERTISSEMENT EN CALIFORNIE:** Risque de cancer et de troubles de la reproduction en raison de l'exposition au nickel (composés métalliques et solubles). Consulter www.P65Warnings.ca.gov.
- ⚠ **ADVERTENCIA PARA CALIFORNIA:** Riesgo de cáncer y daño reproductivo por exposición al níquel (compuestos metálicos y solubles). Consulte www.P65Warnings.ca.gov.

LIMITED WARRANTY


All goods sold hereunder are warranted to be free from defects in material and factory workmanship for a period of three years from the date of purchase. Decorative finishes warranted for one year. We will replace at no costs goods that prove defective provided we are notified in writing of such defect and the goods are returned to us prepaid at Sanford, NC, with evidence that they have been properly maintained and used in accordance with instructions. We shall not be responsible for any labor charges or any loss, injury or damages whatsoever, including incidental or consequential damages. The sole and exclusive remedy shall be limited to the replacement of the defective goods. Before installation and use, the purchaser shall determine the suitability of the product for his intended use and the purchaser assumes all risk and liability whatever in connection therewith. Where permitted by law, the implied warranty of merchantability is expressly excluded. If the products sold hereunder are "consumer products," the implied warranty of merchantability is limited to a period of three years and shall be limited solely to the replacement of the defective goods. All weights stated in our catalogs and lists are approximate and are not guaranteed.

NOTICE: READ ENTIRE MANUAL PRIOR TO INSTALLING PRODUCT.


This Page Intentionally Left Blank

Aqua Sense® Faucets Package Contents


Z6920-XL (As Shown)




Z6922-XL (As Shown)




Required Tools




Smooth Jawed
Wrench



Phillips Head
Screwdriver



Adjustable Wrench
(Optional)




3/32", M3
Allen Wrenches

Overview:

All Configurations:

AquaSense® sensor faucets are ideal for high-use applications where durability and hands-free operation are necessary. ADA compliant, battery powered, polished chrome-plated cast brass sensor faucet with infrared proximity sensor for retrofit and new construction. Unit is furnished with a standard 0.5 GPM aerator and mounting hardware.

Zurn Lead Free products (-XL) are designed and manufactured to comply with Section 1417 of the Safe Drinking Water Act (SDWA) which mandates the weighted average lead content of no more than 0.25% of the wetted surface.



Electronics Box
with Solenoid Valve

Specifications (Electronics Box with Solenoid Valve):

Power:	7.5 VDC external power supply
Sensor Range:	Fixed
Operating Water Pressure:	10-125 psi
Operational Water Temperature:	33°F to 140°F (1°C to 60°C)
Aerator:	0.5 GPM Vandal-Resistant (Standard)

Important Safety Information (All Configurations):

- Installer is responsible for ensuring the product is installed and conforms to all plumbing codes and ordinances.
- Do not convert or modify this Zurn product yourself. All warranties will be voided.
- Water supply lines must be sized according to building designer in order to provide adequate water supply for each fixture.
- Flush all water lines prior to making connections.

Prior to Installation (All Configurations):

Before installing your Zurn® Aqua-Sense® Faucet, the items listed below should already be installed on site:

- Lavatory/sink
- Drain Line
- Hot and cold water supply line or pre-tempered water supply line.
- Installer/Serviceur should not use pipe dope or teflon/thread sealant anywhere on this product, most notably threads and connection points.
- Care shall be taken when installing this product to prevent marring of any exposed or decorative surfaces.




Be sure the sink/lavatory/basin is clear from any objects upon making the sensor to electronics connection.

NOTE: The information in this manual is subject to change at any time without notice. Installations may be performed at different times of construction by different individuals. For this reason, these instructions should be left on-site with the facility or maintenance manager.

Cover Plate Installation Instructions (Z6920 Only)

1. (For faucets with -CP4 or -CP8 suffix).

Pass sensor connector wire and shank through gasket. Align gasket with faucet bottom and press firmly together. Pass sensor connector and shank through cover plate and fasten to the faucet with the provided screws.




Spout Installation Instructions (All Configurations)

NOTE: Before installation, turn off water supplies to existing faucet and remove faucet if replacing an existing device. Clean the faucet basin and clear away debris. Flush all supply lines before connecting the faucet. Failure to do so may result in debris clogging the inlets and/or internal control and mixing valve of the faucet.


1. Carefully screw aerator into spout using included tool.

⚠ Take care to not pinch blue o-ring




- 2a. (Z6920): Install spout to sink using spout base gasket, plastic mounting washer, star washer and mounting nut.

Note: Faucet location needs to be within 3 feet radius above electrical outlet for ACA configurations.




- 2b. (Z6922): Install spout to sink wall using spout base o-ring, plastic mounting washer, mounting nut, and shank elbow.

Note: Faucet location needs to be within 3 feet radius above electrical outlet for ACA configurations.




3. Ensure that slot in plastic washer is facing forward.

⚠ Sensor cable should not pass through plastic mounting washer.




Electronics Module Installation Instructions


1. Assemble the electronics module




2. For battery-powered version, connect sensor inline connector to electronics module.




3. Open battery module using supplied Allen wrench and install supplied batteries in the electronics module.



3a. Optional ACA version: Connect supplied inline connector and AC adapter.




3b. Optional HW6 (Hardwired 6V) version: Connect supplied inline connector and hardwire adapter. When securing the CWB wires to the screw terminals on HW6 unit, the BLACK WITH DASHED MARKINGS should be connected to the Positive (+) terminal, and the SOLID BLACK wire should be connected to the Negative (-) terminal.




Optional MJ unit (sold separately)

Note: Do not connect more than 3 boxes to a single transformer




4. Tighten electronics module assembly to shank and connect water line(s).




5. Ensure that sink is clear of tools/debris and is in normal operating condition.

6. Turn on water supply(ies). Water supply must be turned on in order for sensor to perform wet calibration step.




7. Connect sensor inline connector to sensor cable from spout.




 Do not engage the sensor for 30 seconds after the connection is made. The sensor will perform automatic calibration.

Spout Replacement

To replace spout body, you must first turn water off, then remove spout.



Turn the spout nut to loosen the spout for removal.



Lift spout up to remove spout.

Care and Cleaning Instructions (All Configurations)


- Do not use any abrasive or chemical cleaners to clean the faucets. Do not use any cleaners with an acid base.
- If abrasives or chemicals are used it can lead to dulling of luster, attacking of chrome plating or decorative finishes.
- ONLY use mildly warm soapy water, and then wipe the device dry with a clean/soft towel or cloth.
- Upon cleaning other areas of the restroom be sure the sensor lenses are protected from other cleaning chemicals/solvents to prevent potential damages to the sensor and/or electronics.

Trouble Shooting: Faucet (Solenoid Valve)


Problem	Possible Cause	Corrective Action
Faucet is non-responsive	Battery voltage low.	Change out batteries or verify power provided by HW6 or ACA
	Sensor and electronic connector cable has bent or broken pins.	Check to see if pins are missing, bent, or broken. If yes, then the electronic box needs replaced
	Sensor lens could have surface damage, scratches, or deposit build ups.	Inspect the sensor lens. May require cleaning with a damp cloth or spout/sensor replacement
	Sensor lens could be obstructed by environmental factors such as highly reflective surfaces or bright lighting conditions.	Direct sunlight could effect unit operation. Do not allow direct sunlight onto unit.
Faucet does not activate after initial installation	Sensor may not have had enough time to calibrate prior to a user or target trying to initiate activation.	Disconnect the sensor and electronic box cables and wait for 30 seconds. Reconnect the cables, but allow for another 30 seconds before placing hands or a target within the sensor range. You should hear a click of the solenoid once calibration is complete
	Check if protective film was removed from lens.	
Water does not stop	Electronics box cable connector has bent pins that are shorted	Check to see if pins are missing, bent, or broken. If yes, then the electronic box needs replaced
Ghost Activation	Sensor lens could be obstructed or environmental factors such as high reflective surfaces and/or bright sunlight conditions could be present.	Check/clean sensor lens of any debris or buildup and remove any obstructions. If sunlight or IR interference is a factor, adjust lighting conditions and/or remove nearby reflective surfaces.
Sensor faucet is leaking underneath the sink or counter	Mounting hardware is not tightened sufficiently (faucet shank, electronic box, supply hoses, etc)	Check and ensure the nuts and joints are tight and secure from the supply stop all the way to the faucet shank
	Missing the washer located in the solenoid box nut where it assembles to the faucet shank	Make sure the water supply stops are shut off. Check to ensure the washer is installed or damaged. If not, install washer. If a washer is damaged, replace with new

For further assistance with troubleshooting visit <http://www.zurn.com>


Filter and Mixing Valve Installation





*P6900-120BC,
Filter in standard faucet installation*



*P6900-MV-ADAP [Supplied Adapter]
for -MV & -TMV-1 Options*



Z6920-XL & Z6922-XL Parts List



Description	Product No.
Item 1: 5 3/8" Gooseneck Spout with Nut	P6900-GB
Item 2: 0.5 GPM Vandal Resistant Female Spray Outlet	G62620
Item 3A: Z6920 No Lead Spout Base with Sensor Assembly,	P6922-XL-2
Item 3B: Z6922 No Lead Spout Base with Sensor Assembly,	P6922-XL-1
Item 4A: Z6920 Mounting Kit	P6900-43
Item 4B: Z6922 Mounting Kit	P6922-43
Item 5: -CWB Pigtail	P6900-CWB

Description	Product No.
Item 6: Plug-In Power Converter	P6900-ACA
Item 7: Filter Kit	P6900-120BC
Item 8: Filter Screen	P6900-MV-7
Item 9: Mixing Valve with Filter	P6900-MV-XL
Item 10: Composite Mixing Valve Adapter	P6900-MV-ADAP
Item 11: Electronics Box with Solenoid	P6900-B-L
Item 12: 4" Cast Cover Plate w/ Gasket	P6900-CP4
Item 13: 8" Cast Cover Plate w/ Gasket	P6900-CP8
Item 14: Z6920 Base Plate Gasket	P6920-42-WEDGE

This Page Intentionally Left Blank

