MODEL 48

NRS Assembly – 2 1/2" to 12"

Repair Kit Components	2 1/2" - 12"							
Item #	Item Description	RK212-48	RK3-48	RK4-48	RK6-48	RK8-48	RK10-48	RK12IN-48
1	Hold Down Bolt							
2	Hold Down Washer							
3	Handwheel							
	OP Nut (Not Shown)							
4	Stem Ring Wiper	●	●	●	●	●	●	●
5	Gland Flange Bolt							
6	Gland Flange							
7	Gland Flange O-Ring	●	●	●	●	●	●	●
8	Stem Seal O-Ring	● (x2)	● (x2)	● (x2)	● (x2)	● (x2)	● (x2)	● (x2)
9	Stem Seal O-Bushing							
10	Upper Thrust Washer							
11	Stem							
12	Lower Thrust Washer							
13	Stem O-ring	●	●	●	●	●	●	●
14	Bonnet							
15	Bonnet Bolt							
16	Bonnet Washer							
17	Stem Nut							
18	Wedge							
19	Bonnet Seal	●	●	●	●	●	●	●
20	Body - FLG X FLG							
	Body - GRV X FLG							
	Body - GRV X GRV							
21	Bonnet Lock Washer							
22	Bonnet Nut							
23	PI Plate (Not Shown)							
24	PI Plate Bolt (No Shown)							


Whole Goods (Available for individual sale)								
Item #	Item Description	2 1/2"	3"	4"	6"	8"	10"	12"
25	Gate Valve, NRS (FXF)	212-48	3-48	4-48	6-48	8-48	10-48	12IN-48
	Gate Valve, NRS (GXG)	212-48G	3-48G	4-48G	6-48G	8-48G	10-48G	
	Gate Valve, NRS (GXF)	212-48GXF	3-48GXF	4-48GXF	6-48GXF	8-48GXF	10-48GXF	

Item No.	Repair Kit Description
2 1/2" - 12"	
RK212-48	Repair Kit, 2-1/2" Model 48 (NRS ONLY) Rubbers, Wedge not included
RK3-48	Repair Kit, 3" Model 48 (NRS ONLY) Rubbers, Wedge not included
RK4-48	Repair Kit, 4" Model 48 (NRS ONLY) Rubbers, Wedge not included
RK6-48	Repair Kit, 6" Model 48 (NRS ONLY) Rubbers, Wedge not included
RK8-48	Repair Kit, 8" Model 48 (NRS ONLY) Rubbers, Wedge not included
RK10-48	Repair Kit, 10" Model 48 (NRS ONLY) Rubbers, Wedge not included
RK12IN-48	Repair Kit, 12" Model 48 (NRS ONLY) Rubbers, Wedge not included

MODEL 48

NRS Assembly – 2 1/2″ to 12″

Parts Drawing



NOT SHOWN

23 POST INDICATOR PLATE

24 POST INDICATOR PLATE BOLTS